


SIMPLEX+ QUICK GUIDE

QGSP55000389EN





SETTINGS:



Volume: (4 levels, change using + and -).



Ground Balance: Pump the coil up and down while pressing the Pinpoint/Confirm Button to ground balance automatically.



Iron Volume: Adjusts or turns off the volume of the low iron tone (3 levels, change using + and -).



Threshold: In the All Metal mode, the threshold setting for each sensitivity level is optimized to provide the best performance on different terrains. (Adjust between -50 +50 using + and -)



Notch Discrimination: Eliminate unwanted metals from detection such as trash. Each box represents a group of 5 IDs Any combination of these boxes can be rejected or accepted.

Automatic:

- 1) Swing the search coil over the metal you want to eliminate. The box that represents the group of IDs for that metal will be highlighted in black.
- 2) Press the confirm button.

Manual:

- 1) An X and a check mark will appear on screen along with a small arrow cursor underneath the ID bar at the top of the screen.
- 2) Move the arrow cursor using the plus (+) and minus (-) buttons and select the box that includes the ID you want to eliminate.
- 3) Press the confirm button. The box will be highlighted in black.



Frequency Shift: Eliminates EMI (3 levels, change using + and -).



Wireless: 0=Off / Channels 1-5 (change using + and -).



Vibration: On/Off (change using + and -).



Brightness: Adjusts the LCD and keypad backlight. 0=Off / 1-4 / A1-A4= Auto (lights up only for a short period of time when a target is detected or while navigating the menu and then it goes off).



LED Flashlight: On/Off (change using + and -).

Just turn your detector on, ground balance if you need to and start swinging your coil. Happy metal detecting with the SIMPLEX+!
For more details, please read the user manual.